

PRODUCT DATA SHEET - PTI ENAMEL SERIES

PT-381 GLOSS ENAMEL TOPCOAT PT-382 SEMI-GLOSS ENAMEL TOPCOAT PT-383 FLAT ENAMEL TOPCOAT

DESCRIPTIONNI eLRIEhO 1el O 1gelióla O 1]TJisge(04()l-3()y2Jap14 TETBlicaETleO 1 7217024 h)6.94 Tmh

Our "TTE" enamel coatings are high performance, single component enamel topcoats designed for interior use on high performance general aviation, business jet, and commercial aircraft. These coatings are excellent exterior coatings on substrates that are not subjected to harsh environments. PTA5TITJETBTF164tmh6TJETBTT 0 0 1 338.81T6.9452.74m

TTE Series 4/24/2018



PRODUCT DATA SHEET – PTI ENAMEL SERIES

APPLICATION

This product can be applied by brushing, rolling conventional air spray equipment or HVLP Spray system. Please consult with a PTI representative for specific equipment recommendations and settings.

- 1. Make sure pots, guns, and lines are purged and cleaned.
- 2. Mix both base and thinner thoroughly and filter/strain before spray application. **NOTE**: It is not recommended to strain flat/matte coatings.
- 3. HVLP Spray Pressure: 7-10psi. Conventional Spray System, 15 30 PSI
- 4. Always air-blow and tack wipe the surfaces to be painted. Aircraft should be grounded to prevent static.
- 5. Best application results: apply 2 coats: 1 fog/tack coat & 1 full coats from 0.6 1 mil thickness.
- 6. Do not allow more than 48 hours to pass before applying the second coat.
- 7. Recommended Dry Film Thickness is 1-2 mils. Some colors may require thicker films to achieve hiding.

NOTE: Application of PTI products requires the use of all OSHA approved safety equipment, including proper ventilation. Additionally, PTI products require the recommended temperature/humidity conditions and film thickness ranges for optimal performance. The material, hangar, and aircraft skin temperatures should be no lower than 75° F / 25° C before, during and after application.

DRYING & CURING SCHEDULE

Dry times are based on the dry film thickness between 1-2 mils (25-50 microns).

Air Dry Times (75°F / 25°C and 50% Relative Humidity)

Dries to touch in 1-2 hours; dries hard in 8-10 hours.

EQUIPMENT CLEANUP

Use clean PT-1022X66 Thinner. Do not allow material to dry or cure inside any equipment.

HEALTH, SAFETY, & STORAGE REQUIREMENTS

Refer to each individual material SDS (Safety Data Sheet) for specific requirements on the health, safety, storage and handling requirements. Follow all local, state, and national regulations during surface preparation, material application and cleanup.

PRODUCT INFORMATION & DISCLAIMER

Product Data Sheets are periodically updated to reflect new information. It is important to use the latest and most recent revision for the product being used. The foregoing information is accurate to the best of our knowledge. However, due to differences in customer handling, use and method of application which are not known and are beyond our control, Products Techniques, Inc. makes no warranties as to the end result.

TTE Series 4/24/2018