











P/N	Description	Photo / Scheme
ONA01	Spray lubricant Tire Up	-
ONB01	Spray anti-puncture	-
ONC01	Brake bleeding kit	
OPA03	Bent adapter for wheel valve (tire inflate)	
OT160	Adapter for wheel valve (tire inflate) with fairing	
OPA04	Wrench adapter for axle nut ECR-002 on FUS-009.2 (square 1/2")	
OPA05	Wrench adapter for nut ECR-001 (square 3/4")	
OPA07	High pressure pump 0-20 bars	
OPA12	High pressure pump 0-30 bars	
OPA08	Wrench adapter for nut ECR-002 on AV-VANS-200 axle (square 1/2")	
OPA09	Milling cutter Ø20	
OPA10	Wrench adapter for nut ECR-002	

P/N	Description	Photo / Scheme
OPA11	Wrench adapter for nut ECR-004 (square 3/4")	
OHT02	Metric tool kit	
OUT-046(A) (Ancien OHT01)	Tightening tool for nut E-C-002 - M25x1.5 (hexagonal 19mm)	
OUT-047	Tightening tool for nut E-C-001 and E-C-004 (hexagonal 19mm)	
OUT-078	Wrench for Rotax filter	
OT-001 OT-001.1	Tire mounting tool : • 6" HE wheel • all other 6" wheels	
OT-002	Tire mounting tool : 5" wheel	
OT-003	Wrench to tighten wheel caps BH-001 (BCH-005)	
OT-012	Tire mounting tool : 8" RF-10 wheel	
Av-PIL-101	Special wrench to tighten wheel caps BCH-001	

Contacts

Webshop

Aurore Patents

History/ Values

Certified kits/STCs

Exp. Kits

SensAIR®

Landing Gears  
ALG/B'Flex  
Shock Wheel

Wheels/Brakes

Nose-Tailwheels

Tires

Wheel Axles

Brake Controls  
Rudd'Air PedalsRegulators  
Anti-skid

Parking Valves

Hoses/Fittings

Spare Parts

Tools

FAQs

BERINGER Aero  
Technology

They trust us